

WAYPOINT® 300

RECHARGEABLE HIGH LUMEN, LONG-RANGE PISTOL GRIP SPOTLIGHT



LED charging indicator



Secondary rotary switch selects high, medium, and low modes



Integrated stand for hands-free lighting



Includes 120V AC or international AC charge cord

- Material/Lens** High impact polycarbonate housing. Unbreakable polycarbonate lens, O-ring sealed. Rubberized lens ring and cushioned-grip handle. Available in yellow and black.
- Dims/Weight** Length: 6.75 in. (17.15 cm); Height: 7.14 in. (18.14 cm); Head Diameter: 3.62 in. (9.20 cm)
1.52 lb (691 grams)
- Light Source/ Output** White LED technology, impervious to shock with a 50,000 hour lifetime. Deep-dish parabolic reflector produces a long range targeting beam with optimum peripheral illumination. Optimized electronics provides regulated intensity.
- High, Medium or Low modes:
- High: 1,000 lumens; 270,000 candela; 1,039m beam; runs 3.75 hours
 - Medium: 550 lumens; 135,000 candela; 735m beam; runs 7.5 hours
 - Low: 35 lumens; 10,000 candela; 200m beam; runs 87 hours
- Switch** Trigger style switch with momentary or click on/off operation. Secondary rotary switch selects output mode.
- Battery/ Charging** Lithium Ion Battery. Fully recharges in 4 hours and charges battery in product.
Charge indicator LED: Red – Charging; Green – Charged
- Features**
- LED Solid State Power Regulation provides maximum light output throughout battery life
 - IPX8 rated design; waterproof to 2m, 1m impact resistance tested
 - Light floats if dropped into water
 - Integrated stand for hands-free scene lighting
 - Removable lanyard
- Approvals** Meets applicable European Community directives. CEC Compliant.
- Warranty** Streamlight warrants this product to be free of defects for a lifetime of use except for batteries and bulbs, abuse and normal wear. We will repair, replace or refund the purchase price of this product should we determine it to be defective. This limited lifetime warranty also excludes rechargeable batteries, chargers, switches and electronics which have a 2 year warranty with proof of purchase. **THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW.** You may have other specific legal rights which vary by jurisdiction. Visit streamlight.com for full warranty information.

Item	UPC	Part #
Waypoint 300 120V AC - Yellow	080926-44910-7	44910
Waypoint 300 120V AC - Black	080926-44911-4	44911
Waypoint 300 International - Yellow	080926-44920-3	44920
Waypoint 300 International - Black	080926-44921-3	44921